


# Installation

## 1 Cleaning the air hose

- A 3/8" air hose is required, with a maximum length of 25 ft.
- Clean the air hose of accumulated dust and moisture before connecting it to the air supply.



**NOTE:** If a longer air hose is required, connect a 1/2" air hose to the 3/8" air hose to ensure the air saw has the necessary air supply.



## 2 Connecting to the air supply

- Always use clean dry air. Excessive moisture and dirt will greatly reduce the life of any air motor. We recommend the installation of an in-line filter-regulator-lubricator as close to the tool as possible.
- Ensure all hoses and fittings are the correct size and secured tightly.

Recommended Air Line Set-Up

| Part | Description                 |
|------|-----------------------------|
| A    | Vibration Damped Air Hammer |
| B    | Quick Plug                  |
| C    | Quick Coupler               |
| D    | Air Hose                    |
| E    | In-line Regulator           |
| F    | In-line Lubricator          |
| G    | In-line Filter              |
| H    | Air Compressor              |

